SANUPS

ONLINE UPS


A11J





SANYO DENKI

SANUPS A11J



[Number of phases, wires]	Output capacity		Backup time*	I/O connector
Input/Output AC voltage	(kVA)	(kW)	Баскир ише	I/O CONNECTOR
[Single-phase 2-wire] 200 V model 200/208/220/230/240 V	5	4.5	6	Terminal block
	10	9	J min	

^{*} At a load power factor of 0.8; 4 minutes at a 0.9 load power factor.

Enhanced Reliability with Self-Diagnosis

- Battery self-tests can be performed automatically at regular intervals, ensuring reliable UPS operation in the event of a power failure.
- Batteries can be tested without power interruption.

Note: Battery test interval can be set by the user.

Start battery testing



Return to normal operation

High Energy Efficiency

- Delivers a conversion efficiency of 93%.
- This reduces running costs and contributes to energy saving.

Space-Saving Installation

With a rotatable LCD panel, the A11J can be installed vertically or mounted in an EIA standard 19-inch rack, enabling easy integration into a wide variety of applications and locations.



Rack support rails are optional.

High Power Factor


 With 0.9 output power factor, A11J can protect high power devices such as servers, measuring devices, and medical equipment without the need to oversize the UPS.





Wide Input Voltage Range

- With its wide voltage range from -40% to +15% of the rated voltage at a 70% load level or less, the A11J can handle unstable voltages.
- This minimizes unnecessary battery operation for extended battery life and enhanced reliability.

Front/Rear Indicators and connections







Network Options

Item	Model	Description	
LAN interface card	PRLANIF011B-US	A complete UPS monitoring, control, and shutdown solution over network. It can send a report of UPS status and notify users of power problems via e-mail.	
	PRLANIF013B-US (Environmental monitoring)	Combined with our temperature sensor (PRLANSN001) and humidity sensor (PRLANSN002), this model enables you to monitor UPS ambient temperature and humidity.	
SANUPS SOFTWARE	PMS50B00E (Windows version without cable) PMS51B00E (Multi-OS version* without cable)	This software can automatically shut down protected computer systems in a coordinated manner and stop the UPS in the event of power failure.	

^{*} Supports Windows, Unix, and Linux.

Specifications

Model (UL-registered no	.)			A11J502U002T	A11J103U002T	
Type (Order no.)				A11J502A002TU	A11J103A002TU	
Rated output capacity N configuration (Apparent power /active power) N+1 configuration		5 kVA / 4.5 kW	10 kVA / 9 kW			
				_	5 kVA / 4.5 kW	
System Topology Cooling method Inverter			True online double conversion			
		Forced air cooling				
		High-frequency PWM				
UPS classification accor	ding to IEC standard			VFI-SS-111		
AC	Number of phases/wires			Single-phase 2-wire		
input	Rated voltage			200/208/220/230/240 V (Selectable. Factory setting: 200 V)		
	Voltage range(1)			Within -40% to +15% of rated voltage		
	Rated frequency			50/60 Hz (Auto-detection/Fixed frequency settings selectable. ¹²⁾ Factory setting: Auto-detection setting)		
	Required capacity	N configuration		5.5 kVA or less 11 kVA or less		
	(max. capacity at full charge)	N+1 configuration		_	6.2 kVA or less	
	Power factor			0.95 or greater (at rated input voltage with input voltage harmonic distortion < 1%.)		
AC	Number of phases/wires			Single-phase 2-wire		
output	Rated voltage (sam			200/208/220/230/240 V (Factory setting: 200 V)		
	Voltage regulation			Within ±2% of rated voltage		
	Rated frequency (s	same as input)		50/60 Hz		
	Frequency	At normal operation (utility-synchronous)		Within ±1, ±3, or ±5% of rated frequency (factory setting: ±3%)		
	regulation(2)	At free run (assynchronous)		Within ±0.5% of rated frequency		
	Voltage waveform		,	Pure sine wave		
	Voltage harmonic of	distortion		< 3% / 8% (at linear load / rectifier load, rated output)		
	Transient	Abrupt load cha	ange	Within ±5% (for 0 ⇔ 100% load step changes)		
	voltage	Loss or return of input power		Within ±5%		
	regulation	Input voltage change		Within ±5% (for ±10% abrupt voltage changes)		
	Load power factor	N configuration		0.9 lagging (from 0.7 lagging to 1.0)		
		N+1 configur		0.9 lagging (from 0.7 lagging to 1.0)		
	Overcurrent protect	Overcurrent protection		110% or greater		
	(automatic swith to		N configuration N+1 configuration	_	220% or greater	
	Overload	Inverter	N configuration	110% / 118%		
	capability	(1 min) / (Instantly)	N+1 configuration	_	220% / 236%	
		Bypass	N configuration	200% / 800%		
		(30 s) / (2 cycles)	N+1 configuration	_	400% / 1600%	
Battery	Type		1111 comigaration	Small-sized valve-regulated lead-acid (VRLA) battery		
,	Number of batterie	s (12 V ner hatte	rv)	16 32		
	Rated capacity of a		, , ,	5 Ah	102	
	Backup time	a battory		5 min (at 25°C ambient temperature and 0.8 load power factor, under factory conditions)		
Input leakage current	•			4 mA or less 8 mA or less		
Acoustic noise (at 1 m f	from the front of unit)		45 dB or less	50 dB or less	
				339 W	730 W	
Operating environment	at rated output after fully recharged) nent Ambient temperature			0 to 40°C		
operating environment	Relative humidity			20 to 90% (Non-condensing)		
I/O connector, wiring,	I/O connector			Field wiring terminal block. Compatible wire gage: 20 to 4 AWG		
etc. (4)	Input wire			8 mm² (6 AWG) 22 mm² (4 AWG)		
	Output wire			8 mm² (6 AWG)	22 mm² (4 AWG)	
	Grounding wire			5.5 mm² (6 AWG)		
	I/O breaker capacity			35 A (UL 489 listed unit) 80 A (UL 489 listed unit)		
Safety standard				UL 1778 5th edition (E226092), CSA C22.2 No. 107.3-14 (3rd edition), CE marking (EN 62040-1:2008/A1:2013)		
EMC standard				EN 62040-2:2006 Category C3, EN 55022:2010, FCC Part 15 Subpart B Class A		
LIVIO Stallualu	Immunity			EN 62040-2:2006 Category C3, EN 35022:2010, FCC Part 15 Suppart B Class A EN 62040-2:2006, EN 55024:2010		
	iiiiiiiiiiiiiiiiiiiiiiiiiiiiiiiiiiiiiii			LIN 02070*2.2000, LIN 03027.2010		

Note: both Japanese and English operating manuals are included with these UL/CE certified models.

At load level ≤ 70%: -40% to +15%

At load level > 70%: -20% to +15%

Note that at a 70% load level or less, the lower limit value is -40% when leaving the range and -20% when returning.

Allowable frequency range is within ±8% of the rated value at this setting.

When fixed frequency setting is selected, output frequency is fixed to either 50 Hz or 60 Hz regardless of input frequency. Allowable frequency range is from 40 to 120 Hz at this setting.

Note that when returning from outside the allowable range, the range limits will be $\pm 8\%$ for both settings.


- Also, for the inverter to start running, the input frequency must be within the set synchronizing frequency range $(\pm 1\%, \pm 3\%, \text{ or } \pm 5\%)$.
- (3) Uninterrupted transfer to bypass operation is only possible when all of the following conditions are true: automatic frequency detection setting is selected; input frequency is within the synchronizing range; input voltage is within the allowable range.
- 1. Dry contact signal: D-Sub15 female, fixed mounting screws: M3 $\,$
- 2. PC port: D-Sub9 male, fixed mounting screws: #4-40UNC


Remote control: One-touch terminal block connector, compatible wire size from 26 to 20 AWG $\,$

⁽¹⁾ AC input voltage range changes depending on the load level.

 $^{^{[2]}}$ When the automatic frequency detection setting is selected, $\pm 1\%$, $\pm 3\%$ (factory setting), or $\pm 5\%$ frequency synchronizing range is available for selection.

Dimensions (unit: mm)






Paint color: Black (Munsell N1.5)

Options

Item	Model	Description
Transformer box, plug type	TRA11J502A00NRM	10 inch and a supplied to the s
Transformer box, terminal block type	TRA11J502A00TRM	19-inch rack-mountable transformer for converting single-phase 2-wire 200 VAC to 100 VAC.
Power distribution box	PDBA11J103A02C	This product supplies UPS power to a number of devices in the event of a power failure.
Rack support rail	RM027	A pair of left and right rails for mounting a UPS into a standard 19-inch rack.

Rack Support Rail Dimensions (unit: mm)



Notes before Purchase

- Before installing, assembling, and using the product, please read Instruction Manual carefully and use it properly.
- When using this product in the following applications, consult us in advance because special considerations are required for operation, maintenance, and management.
 - (a) Medical equipment that may have direct effects on human life or human body.
 - (b) Trains, elevators, and other machinery that can cause injury.
 - (c) Socially and publicly important computer systems.
 - (d) Other equipment that is related to safety of human life and that can have major impact on maintenance of public functions.
- For use in an environment where vibration is present, such as in a car or a ship, please consult us in advance.
- •Never attempt to disassemble or alter the product in any way.
- For installation and maintenance work of the product, please consult us or properly licensed personnel.
- Products listed in this catalog may be regulated by export laws and regulations in each country. When exporting these products, compliance with each country's respective export laws and regulations is highly recommended.
- ◆SANYO DENKI will not be liable for any direct or indirect damages or loss, including but not limited to equipment downtime, missed power sales revenue, business interruptions, increased power purchases, resulting from the use of or inability to use our products or services.

Note: For any inquiry or consultation, please contact our sales department.

Product web page:https://www.republicpowersystems.com/products/a11j/

REPUBLIC POWER SYSTEMS

601 Quail Valley Drive Georgetown, TX 78626

https://www.republic power systems.com

email: sales@republicpowersystems.com

TEL: (512) 686-1876

SANYO DENKI AMERICA,INC.

468 Amapola Avenue Torrance, CA 90501, U.S.A.

http://www.sanyodenki.us